



**1.** Remove bottom glass riser. Slide up and out. Place Safely in cabinet.



**2.** Place screen into cabinet. Angle forward.



**3.** Slide the top up between the inside top front edge and the night blind.



**4.** Pull the screen forward inserting the padlock ring through the slot in the bottom night blind hook.



**5.** Fit padlock through the padlock ring.

| SECURITY SCEEN PART NUMBERS |             |
|-----------------------------|-------------|
| MODEL                       | PART NUMBER |
| BTGOR6                      | X000623     |
| BTGOR9                      | X000622     |
| BTGOR12                     | X000621     |
| TTGOR6                      | X000620     |
| TTGOR9                      | X000618     |
| TTGOR12                     | X000619     |