



F90-713 C4ABC9 Part list

Part No	Name	Qty
S16-566	BLOWER	1
S16-388	TERMINAL BLOCK	3
S16-465	LAMP	4
S16-466	STARTER	4
S16-467	LAMP HOLDER	4
S16-480	LAMP CLIP	8
S16-468	BALLAST	4
S16-469	CONNECTOR, 3-PIN	4
S19-008	RUBBER FOOTING	4
S19-027	LEG, TUBULAR	4
S21-027	ROLLER GUIDE	2
S99-180	DOOR HANDLE, REAR GLASS	2
F90-335	S21-028 GLASS FRAME	2
(left)	S21-028 GLASS FRAME	2
F90-360	S19-326 ROLLER	4
(right)	S21-015 PVC STOPPER	3
	S21-013 RUBBER SEAL	2
	S99-007 SEAL	4
A56008	Rubber, Padding	2
S21-020	Ticket strips of deck	1
S21-021	SIDE GLASS LEFT	1
	SIDE GLASS RIGHT	1
F90-333	S21-022 GLASS PANEL, FRONT	2
(left)	S21-012 DOOR HANDLE, FRONT GLASS	2
	S21-013 RUBBER SEAL	2
F90-359	S19-326 ROLLER	4
(right)	S21-015 PVC STOPPER	3
	S99-007 SEAL	4
	S21-028 GLASS FRAME	2
S25-067	S21-060 Rubber, Padding	2
S25-068	WIRE SHELF, UPPER	2
S25-064	WIRE SHELF, UPPER	1
S25-065	WIRE SHELF, LOWER	2
S25-063	WIRE SHELF, LOWER	1
S25-066	WIRE SHELF, MID	1
S16-571	WIRE SHELF, MID	2
F92-371	CEILING FAN	1
A20031	New Top Hood	1
	Ticket Strips	3