



F90-715 C4HT9 Part list

Part No	Name	Qty
S16-491	HEATER	1
S01-058	BLOWER	3
S16-653	THERMOSTAT	1
S16-452	CIRCUIT BREAKER	1
S16-388	TERMINAL BLOCK	3
S16-466	LAMP	3
S16-466	STARTER	3
S16-467	LAMP HOLDER	3
S16-480	LAMP CLIP	6
S16-468	BALLAST	3
S16-469	CONNECTOR,3-PIN	2
S19-008	RUBBER FOOTING	4
S19-027	LEG, TUBULAR	4
S21-027	ROLLER GUIDE	2
S99-180	DOOR HANDLE, REAR GLASS	2
F90-335	GLASS FRAME	2
(left)	S21-028 GLASS PANEL,REAR	2
F90-360	ROLLER	4
(right)	S19-326 PVC STOPPER	3
	S21-013 RUBBER SEAL	2
	S99-007 SEAL	4
A20049	Rubber, Padding	2
S21-020	Ticket strips of deck	2
S21-020	SIDE GLASS LEFT	1
S21-021	SIDE GLASS RIGHT	1
F90-333	GLASS PANEL,FRONT	2
(left)	S21-012 DOOR HANDLE, FRONT GLASS	2
F90-359	ROLLER	4
(right)	S19-326 PVC STOPPER	4
	S99-007 SEAL	4
S25-067	GLASS FRAME	2
S25-064	Rubber, Padding	2
S25-064	WIRE SHELF,UPPER	2
S25-063	WIRE SHELF,MID	2
S25-068	WIRE SHELF,LOWER	2
S25-066	WIRE SHELF,UPPER	1
S25-065	WIRE SHELF,MID	1
S25-066	WIRE SHELF,LOWER	1
A20050	DECK TRAYS	2
S16-571	CEILING FAN	1
S16-479	SENSOR	1
F92-371	New Top Hood	1
A20031	Ticket Strips	3