#### $DTG\ \mbox{HOW}\ \mbox{TO}\ \mbox{Navigate}\ \mbox{the}\ \mbox{Controller}$




Applicable models: DTGOR6 DTGOR9 DTGOR12 DTGOR15



cossiga

 Pull the top of the front grill down

 to reveal the control switches






Turn the power switch on to start the cabinet and get the shelves cooling down to temperature



### $DTG\ \mbox{HOW}\ \mbox{TO}\ \mbox{Navigate}\ \mbox{the}\ \mbox{Controller}$

# cossiga




Turn the Light switch on to turn the under-shelf lighting on





To change to temperature of the cabinet, hold the SET button down on the controller until the °C starts flashing



Press the up or down arrows to change the temperature. Press the SET button to lock in your chosen temperature



When flashing, this green icon means the cabinet is defrosting



## $DTG\ \mbox{HOW}\ \mbox{TO}\ \mbox{Navigate}\ \mbox{the}\ \mbox{Controller}$

## cossiga



When on, this green symbol means the compressor is on



When on, this green symbol means the airflow fans are on

