SAFETY



Always disconnect cabinet before servicing



Servicing should only be carried out by an approved service agent or registered



TOOLS NEEDED

- Medium size phillips screwdriver or drill with phillips head

INSTRUCTIONS

1. Unscrew and remove back panel



2. Unscrew and remove the front panel



3. Remove drainage pipe



4. Lift unit safely with fork lift or pallet jack



5. Place safety poll and wood beam to secure forks



6. Remove existing castors and washers from the cabinet by removing the four securing screws

(Four screws and four washers per castor and four castors per cabinet)

Front castors - Requires mounting plates

Rear castors - **Do not require mounting plates**



7. Front Castors

Place mounting brackets between top of leg extension and bottom of cabinet

Secure in place with nuts and washers and ensure mounting brackets are square



CONTINUED...

8. Adjust mounting plate to allow for thickness of meltica panel



9. Rear Castors

Secure leg extensions in place with nuts and washers

Ensure all nuts and washers are in place and firm



10. Safely lower cabinet to ground and add back the front + back panels

